VENETIAN

Par Light User's Manual

Model: VT-P009

Attention

1. Please read these operating instructions carefully to familiarize you with basic operations of this unit BEFORE USE.
2. Without permitted, it is prohibited to spread the contents of this manual to others.
3. This manual is only to provide related information, and the contents of this manual will be changed at any time without notice.
4. Unless the instructions have already stated, please do not freely modified the unit.

Safety Tips

1. Before installation and maintenance, please confirm the power is OFF. make sure that the ventilation around the unit is good.
2. The lighting is designed for indoor demonstration, please do not use this product in a wet environment for long-term.
3. The use and maintenance of this unit should avoid contact with water. when using it outdoor, please take waterproofing measures.
4. Personnel, who to take the installation, operation and maintenance, must be familiar with the lighting performance. Most of the damage is resulted from unfamiliar with its performance.
5. Please do not face up to the luminous unit for a long time, so as not to cause discomfort to your eyes.
6. Please often wipe the unit with a clean cloth.

Operation Instructions

Item NO.	Display	Description (all the funtions needed, want to active, should press Button "D" to save.)
1	d001	DMX Address.(001-512) B、C button to plus or minus the numerical code.
2	P000	colorful jump, (00-255) the button B and C for adjusting the change speed.
3	L000	colorful fade, (00-255) the button B、C to adjust the change speed.
4	E000	colorful vein banding, (00-255) the button B、C to adjust the change speed.
5	soud	colorful sound-active.
6	r000	Red-selecting, (000-255) Button B、C to adjust the brightness.
7	g000	Green-selecting, (000-255) Button B、C to adjust the brightness.
8	b000	Blue-selecting, (000-255) Button B、C to adjust the brightness.
9	U000	White-selecting, (000-255) Button B、C to adjust the brightness.
10	Y000	Amber-selecting, (000-255) Button B、C to adjust the brightness.
11	F000	Strobe, (000-255) Button B、C to adjust flicker frequency.

Instruction of buttons

Button A: Function button; **Button B:** to increase; **Button C:** to decrease; **Button D:** to save

Operation Instructions: Press Button A will active 11 kinds of different functions. The digit in front of decimal point on the nixie tube indicates the present function. The digit behind the decimal point indicates the function corresponds to the parameter.

Technical Specification

Light source	54x3W(R12 G12 B12 W12 A6)	DMX channel	9
Source lifetime	50,000hours	Effect	Colorful change, strobe
Power supply	100-240V/50-60HZ	Standard configuration	Power cable
Rating power	180W	N.W.	1.7KG
Play mode	Auto/Sound/DMX/Master-slave		

DMX Control

(**Last radix point flickers on digital display board when has DMX signal**)

Item NO.	Function	Instruction
CH 1	Dimming	R G B W A total dimming, linear dimming, from dark to bright
CH 2	Strobe	Strobe speed from slow to fast
CH 3	Function-selecting	0-50:strobe and linear dimming; 51-100: jump-change; 101-150: fade change; 151-200: vein banding; 201-255: Sound
CH 4	Function speed	Corresponding CH 3 function speed, from slow to fast
CH 5	R-Dimming	Red color dimming, linear dimming, from dark to bright
CH 6	G-Dimming	Green color dimming, linear dimming, from dark to bright
CH 7	B-Dimming	BLue color dimming, linear dimming, from dark to bright
CH 8	W-Dimming	White color dimming, linear dimming, from dark to bright
CH 9	A-Dimming	Yellow color dimming, linear dimming, from dark to bright